




233814 UK NSR 200A, 370A Green Black Complete owner instructions.indd 2










Using the Machine



High = 100%







Cleaning the Machine

About the machine

Rating label



Machine yr/wk/serial number

WEEE (Waste, Electrical and Electronic Equipment) Safety Critical Components Vacuum cleaner, accessories and packaging should be sorted for Mains lead environmental-friendly recycling. HO5V2V2-F 2 x 1.00mm² Filter Bag Only for EU countries: do not dispose of Vacuum cleaner into household waste! NVM-1CH >pp< construction 99.6%@0.3µm According to the European Directive 2002/96/EC on Filter waste electrical and electronic equipment and its Tritex NVM 604165 >pp< construction 96.0%@0.3µm incorporation into national law. Vacuum cleaners that are no longer suitable for use NVM 604311 >pp< construction 99.6%@0.3µm Microtex must be separately collected and sent for recovery in an environmental-friendly manner Microfresh NVM 604170 >pp< construction 98.4%@0.3µm

PPE

(personal protective equipment) that maybe required for certain operations.









Safety Gloves Dust / Allergens Protection







NOTE:

A risk assessment should be conducted to determine which PPE should be worn.

| Motor | Airflow | Suction |
|--------------|--|------------------|
| 800W 500W | 30L/sec | 2000mm 1300mm |
| Capacity | Cleaning range | Weight |
| 9L | 31.8m | 6.9Kg |
| Size | Sound Pressure | Protection Class |
| 355x355x415 | 66.7 dB - 62.2 dB (A) (IEC 60704-2-1) Uncertainty 0.2 dB | Class II |

1

Information for DRY USE Vacuum Cleaners WARNING:

Read the instruction manual before using the machine.

Operators shall be adequately instructed on the use of thier machine.

As with all electrical equipment, care and attention must be exercised at all times during use, in addition to ensuring that routine and preventative maintenance is carried out periodically to ensure safe operation.

Failure to carry out maintenance as necessary, including the replacement of parts to the correct standard could render this equipment unsafe and the manufacturer can accept no responsibility in this respect. Maintenance should only be carried out by a qualified person.

This machine is for DRY USE only and must not be stored outside or used in wet conditions.

The machine shall be disconnected from the mains by removing the plug from the supply socket during cleaning or maintenance and when replacing parts or converting the machine to another function.

The machine is not to be used by children or persons with reduced physical, sensory or mental

capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction.

This appliance is intended to be cleaned and maintained by an adult.

Children being supervised are not to play with the machine.

This machine is not a toy.

CAUTION:

This machine is not suitable for picking up hazardous or explosive dust. Contact your local distributor if you require a machine capable of performing these tasks.

Ensure that the filtration system fitted to the machine is suitable for the material being collected.

This vacuum cleaner is intended for indoor use in the collection of dry materials. This machine should be stored indoors only.

NOTE:

8

This machine is also suitable for commercial dry use, for example in hotels, schools, hospitals, factories, shops and offices for other than normal housekeeping purposes. This product complies with the requirements of IEC60335-2.69.

This vacuum cleaner is fitted with a thermal protection device. If the vacuum cleaner stops working, remove the plug from the wall before investigating where the fault lies. If the vacuum cleaner has a blockage, switch off, remove the plug from the wall, inspect the floor tool, tubes and hose for debris. If the floor tool, tubes and hose are clear, replace the dust bag and clean the filter.

The vacuum cleaner should be inspected after use for damage.

Not suitable for the collection of biological hazards, hazardous, or explosive dusts . The vacuum cleaner should be stored in a dry place.

DO:

-Keep your machine clean including hoses and tubes.

-Change dust bag frequently.

-Keep filters clean.

-Keep diffuser filter (where fitted) clean.

-Use filter bags, they will enhance performance and help keep machine clean.

-Use a Numatic Original filter bag under fine dust conditions.

-Keep hoses and tubes clear.

-Replace any worn or damaged parts immediately.

-Only use the socket outlet on the machine for purposes specified in the instructions. -Only use the brushes provided with the machine. The use of other brushes may impair safety.

-Regularly examine the power cord. If damage is found such as cracking or ageing the power cord

must be replaced by a qualified person.

-Only replace the power cord with the correct Numatic approved replacement part.

DON'T:


-Unreel the cable with one pull or pull on the cable to unplug the machine from the power supply.

-Use to suck up hot ashes or lighted cigarette ends.

-Use steam cleaners or pressure washers to clean the machine or use in the rain. -Immerse in water for cleaning.

-Attempt machine maintenance or cleaning unless the power supply plug has been removed from the supply outlet.

Do not use in wet environments or to collect wet materials.



NSR Range (AUTOSAVE)

DRW-5104

9